

## Using your Honeywell Security System

Your MASTER CODE is: \_1234\_\_\_\_\_

Your PASSWORD is: \_\_\_\_\_

To Change your Master Code enter Existing Master Code \_\_\_\_ (1234) then 802 + New Code \_????\_ ( 2 Times )

To arm your system while you are Home:

1. Make sure you have a green ready light. All doors must be closed to have a Green ready light.

2. Enter you master code and press 3. Your RED Armed light will come on. In Approx. one minute your system will arm and no doors can be opened until the system is disarmed.

To arm your system when you are Leaving Home.

1. Make sure you have a green ready light. All doors must be closed to have a Green ready light.

2. Enter you master code and press 2. Your RED Armed light will come on. You must leave within the first minute. Simply walk out the entry/exit door. No one can be in the house. The house must be empty.

To arm your system for BED TIME.

1. Make sure you have a green ready light. All doors must be closed to have a green ready light.

2. Enter your master code and press 7. Your RED Armed light will come on. In approx. one minute your system will be armed and no doors can be opened until the system is disarmed. \*note this takes off the entry delay on all doors\*

To DISARM your security system.

1. Simply enter in your 4 digit master code and press one. This will disarm your security system. Now all you should have on is a green ready light. \*all doors must be closed before you can get the green ready light\*

Panic buttons and features

Ambulance : Press at the same time 1 and the \*.

This will be silent alarm.

Police : Press at the same time \* and the # .  
This will be a constant audible alarm.

Fire : Press at the same time # and the 3 .  
This will be a two pulse audible alarm.

Chime : Enter your four digit master code to activate the chime feature.  
This will make the keypad beep twice when a perimeter or entry exit zone is activated (doors or windows). Repeat to de-activate the chime feature.

Bypass Zone : This will allow you to have your system armed and have certain zones deactivated. Say for example you wanted your front door open for sunlight but wanted the other doors armed. This will allow you to do this. Enter your master code press 6 and then the zone in two digits. ( 01, 02, 03 and so forth ). When the Zone is bypassed you can have that zone open and have a Green light.

Note. Do not panic if you accidentally set the alarm off. Simply enter your master code and press 1 to turn the siren off. If you entered your master code and pressed one within the first minute AVS will probably not call you. If its been longer then a minute, wait by the phone and an AVS operator will call you soon to make sure you are all right. They will ask you for your password then hang up. Remember this system is here to help you and SO ARE WE. AVS [601- 268-1818](tel:601-268-1818)